

INSTRUCTIONS FOR INSTALLATION

1" X 1-1/2" STAINLESS STEEL TUBE WALL POST

WALL MOUNTING

- Determine the location and hand of the 1 x 1-1/2" stainless steel wall post being installed. When wall post is used to hinge a door, outside edge of wall post to be in line with outside edge of keeping stile. When wall post is used as a keeping stile, the wall must have adequate backing at mounting location to support door hung in place. When wall post is used to hinge a door, wall post must support a minimum 250lbs door load.
- Install wall post at given height and fasten, plumb in both directions to wall with (5) wall screws provided. Install (2) post end caps and (5) mounting hole plugs.
- With wall post anchored to wall, through-bolt hinges to post with hinge screws, acorn nut and lock washer. Hinge mounting screw heads should be on outside of stall with lock washers and acorn nuts on the inside.
- Follow standard installation instructions to complete hinge mounting to door.

Parts List

1002245 Packet - 1080 Hinge

1 - 1002246	Stainless Steel Wall Post
5 - 1002248	Mounting Hole Plugs
2 - 1002256	End Cap for Post
5 - 1000085	Wall Screw
6 - 1002501	Screw - Hinge to Post
6 - 1000829	Acorn Nut - Hinge Screw
6 - 576-38	Lock Washer - Acorn Nut

1002250 Packet - 1040 Hinge

1 - 1002251	Stainless Steel Wall Post
5 - 1002248	Mounting Hole Plugs
2 - 1002256	End Cap for Post
5 - 1000085	Wall Screw
4 - 1002501	Screw - Hinge to Post
4 - 1000829	Acorn Nut - Hinge Screw
4 - 576-38	Lock Washer - Acorn Nut

1002254 Packet - 1542 Hinge

1 - 1002255	Stainless Steel Wall Post
5 - 1002248	Mounting Hole Plugs
2 - 1002256	End Cap for Post
5 - 1000085	Wall Screw
4 - 1002501	Screw - Hinge to Post
4 - 1000829	Acorn Nut - Hinge Screw
4 - 576-38	Lock Washer - Acorn Nut

1002275 Packet - 1030, 1040, 1080 I. S. Keeper Post

1 - 1002276	I.S. Keeper Post w/Holes
5 - 1002248	Mounting Hole Plugs
2 - 1002256	End Cap for Post
5 - 1000085	Wall Screw
1 - 1000192	Keeper
5 - 1000207	Sleeve, Rework
10 - 1000204	Screw
5 - 1000087	Insert
10 - 2584-6	Screw
2 - 1000936	Screw
2 - 1000082	Screw
1 - 1002270	Installation Instruction Sheet

1002346 Packet - .67 Institutional Hinge

1 - 1002347	Stainless Steel Wall Post
5 - 1002248	Mounting Hole Plugs
2 - 1002256	End Cap for Post
5 - 1000085	Wall Screw
6 - 1002501	Screw - Hinge to Post
6 - 1000829	Acorn Nut - Hinge Screw
6 - 576-38	Lock Washer - Acorn Nut
5 - 1002495	Torx Screw



In the U.S.A.: BOBRICK WASHROOM EQUIPMENT, INC.

200 Commerce Drive, Clifton Park, New York 12065-1350 • Tel: (518) 877-7444 • FAX: 518-877-5029
11611 Hart Street, North Hollywood, California 91605-5882 • Tel: (818) 982-9600 • FAX: 818-503-1102
100 Bobrick Drive, Jackson, Tennessee 38301-5625 • Tel: (731) 424-7000 • FAX: 731-424-7800

In Canada: BOBRICK WASHROOM EQUIPMENT COMPANY

45 Rolark Drive, Scarborough, Ontario M1R 3B1 • Tel: (416) 298-1611 • FAX: 416-298-6351