

*fino* collection

## Installation Instructions for Grab Bars B-9806 and B-9807 on Dry Walls



To ensure user, installer, and product safety, please use cut-resistant gloves before handling any material prior to installation.

### Required Tools

- A. Bobrick Dry Wall Installation Kit, part no. 9806-20, comprising of
  - b. Wingits® Anchor GBWME 40
  - c. Dry Wall Kit:
    - i. Dry Wall Base
    - ii. Dry wall pillar, replacing standard pillar of flange - no.4 in the drawing below (to reduce increased depth to wall by application of dry wall base in order to maintain same distance to wall for ADA-compliance)
    - iii. 6 pcs. M5x16mm Phillips flat head screws (3pcs. per flange)
- D. Spanner (preferably ring end) 13mm (similar to ½")
- E. Laser/Spirit level
- F. Phillips head screwdriver
- G. Drill for 1 ¼" hole
- H. Waterproof tape



BUILDING VALUE SINCE 1906

© 2024 by Bobrick Washroom Equipment, Inc.  
Form No. 9806-9807-76\_ii Revised 8/29/24

#### In the U.S.A.: BOBRICK WASHROOM EQUIPMENT, INC.


Los Angeles: 6901 Tujunga Ave., North Hollywood, CA 91605-6213; Tel: (818) 982-9600, FAX: (818) 503-1102  
New York: 200 Commerce Drive, Clifton Park, NY 12065-1350; Tel: (518) 877-7444, FAX: (518) 877-5029,  
or e-mail: customerservice@bobrick.com

#### In Canada: BOBRICK WASHROOM EQUIPMENT COMPANY

45 Rolark Drive, Scarborough, Ontario M1R 3B1 • Eastern Canada: Tel: (877) 423-6555 • FAX: (877) 423-8555  
• Western Canada: Tel: (877) 423-6444 • FAX: (877) 423-8444

**“Exploded” overview of the grab bar flange:**

1. Flange Base




6. M8 - Screw, hex head  
(13mm, 1/2" or 9/16")



2. Flange Cover




7. Dry Wall Base



3. Pillar



**WingIts Anchor:**



4. Half-Moon-Washer



5. Knurled Washer



1. Securely fix flange-bases to dry wall at correct pitch (18"/24"/36"/42") using the appropriate fixings. Ensure a minimum of 6" from corners/returns so that a spanner can be used later.

2. Install Wingits anchor with dry wall base:


- Drill 1-1/4" hole into the dry wall.
- Peel one side off of waterproof tape and adhere around drilled hole in wall.
- Remove center screw #4 from Wingits anchor/fastener.
- Insert center screw through dry wall base and rethread into fastener

**Note:** Do not rethread the screw all the way back into the fastener. Hold short by 3/4".

- Insert Wingits anchor/fastener into the wall.
- Push the screw head all the way into the dry wall base until the wings “POP” behind the wall.
- Pull on dry wall base, remove the tape liner - keep dry wall base away from wall as you tighten.


3. Mount flange base to dry wall base. Place flange base into dry wall base and insert M5x16mm Phillips flat head screws (3pcs. per flange) through the flange base into the dry wall base. Screw heads want to be below flush. Use a level to assist in laying out.

3 pcs. M5x16mm  
Phillips flat head screws




**Picture shows flange-base**

4. Fit the flange covers on both flanges with the bevelled edge facing out.




5. Place Dry Wall Pillars on both flanges with flat end to flange (flange cover).


**NOTE:** use Dry wall pillars, replacing standard pillar of flange - no.4 in the explosion drawing above (to reduce increased depth to wall created by the application of the dry wall base in order to maintain same distance to wall for ADA-compliance)




6. Fit Bolt (M8 Screw) & Knurled Washer through Half-Moon Washer. Make sure the shape of the half-moon washer is aligned with the inside diameter of the tube.



7. With the slots in the tube facing down, pass the thread of the bolt (M8 Hex Screw) through the slot in either end of the tube from the inside. Hold the tube and gently twist to help the bolt (M8 Hex screw) pass through the slot. Repeat for other end of the tube while keeping the slots facing down to avoid losing the part just fitted. Make sure the shape of the half-moon washer is aligned with the inside diameter of the tube.



8. Push both threaded bolts (M8 Hex Screws) into flange end hole and finger tighten using the knurled washer on the bolt (M8 Hex Screw). Ensure the radius on the pillar matches the radius of the tube.



Tighten both ends with the ring end of a 13mm spanner making sure not to damage the tube with the spanner. Fit end caps making sure to locate the screwdriver release recess facing down out of casual observation.

# WINGITS®

## Designer Grab Bar Fastener

World's Strongest Fastener®


Model:  
**GBWME**

**Part Numbers:**

**GBWME40**  
Stainless Steel Fastener with  
Plastic Face Plate and 4"  
Stainless Steel Screw



AS EASY AS ...



**Features:**

- Exceeds ADA Guidelines and ALL Building Codes
- NEVER Loosens - World's Strongest Fastener®
- Water Resistant and Fire Retardant
- Used to Install WINGITS® Designer Grab Bars
- Rated up to 800lb in Drywall with Tile
- Eliminates the need for Blocking

<b>MECHANICAL DATA</b>
Length: 2.75" (70mm) Height: 2.75" (70mm) Depth: 4" (102mm)
<b>COMPOSITION</b>
18-8 (304) Stainless Steel with Plastic Face Plate
<b>INSTALLATION</b>
WINGITS® Grab Bar Fasteners (GBWME40) are rated up to 800lb in drywall with tile and designed to install WINGITS® Designer Grab Bars.



Industrial Grade Carbide Drill Bit

- GBWME40 installs quickly and easily with the APACHE200 (WA200GT54)
- Drills holes through ceramic wall tiles in seconds - use cordless drill
- Designed for ceramic, marble & plaster

# Installation Instructions GBWME40

## WINGITS® MODERN Elegance™ Grab Bar Fastening System Installation Guide WINGITS® Grab Bar Fastening Systems Exceeds Building Codes For Grab Bars In The Following Wall Substrates:

- 5/8" Drywall - painted or wallpapered
- 1/2" or 5/8" Drywall with tub surrounds
- 1/2" or 5/8" Drywall with tile, marble or stone
- 1/2" or 5/8" Drywall with any panel types including fiberglass, faux marble, acrylic and plastics
- Multiple layers of Drywall
- Plaster and lath
- 1/4" acrylic / fiberglass tub surrounds
- Most wall panels, all masonry type boards, with or without decorative panels



## WINGITS® MODERN Elegance™ uses Indicator Points to simplify installation.

1. Remove the stand-offs to expose the **INDICATOR POINTS** on the accessory.
2. To ensure adequate clearance, a stud finder should be used to verify there are no studs within the area where the WingIts™ will be installed. Make sure that there is at least 1.5" away from the edge of the stud.
3. Place the accessory in the preferred location and **push on the accessory to mark the points where stand-offs will be mounted.**

## GBWME40

### Installing MODERN Elegance™ Grab Bars

1. Drill 1.25" hole on the marks by the **INDICATOR POINTS**.
2. Peel one side off of waterproof tape and adhere around drilled hole in wall.
3. Remove center **SCREW** completely.
4. Insert **SCREW** through **STAND-OFF** and rethread into fastener.
5. Insert the WingIts™ into the wall.
6. Push the **SCREW** head all the way into the **STAND-OFF** until the wings "POP" behind the wall.
7. Pull on **STAND-OFF**, remove tape liner - keep **STAND-OFF** away from wall as you tighten.
8. Attach Grab Bar and tighten set screws.



View Installation Videos at:  
[www.wingits.com](http://www.wingits.com)

View Installation Videos at: [www.wingits.com](http://www.wingits.com)

Toll Free: 877-894-6448 [www.wingits.com](http://www.wingits.com) [sales@wingits.com](mailto:sales@wingits.com)